

P165C                    '7-pin                    Blue                    Left of Panel

- 1- \_\_\_\_\_
- 2- Run +
- 3- Door Switch
- 4- Ground
- 5- Panel Illum. +
- 6- Panel Illum. -
- 7- Not Used

P165D                    11-pin                    Yellow                    Left of Speedo

- 1- Ignition Control                    (N9TE/ZN3J)
- 2- Run +
- 3- \_\_\_\_\_
- 4- \_\_\_\_\_
- 5- Turbo Boost Gauge                    (XD3T/N9TE)
- 6- \_\_\_\_\_
- 7- Charge Light from Alternator
- 8- Brake Failure
- 9- Brake Wear
- 10- \_\_\_\_\_
- 11- PreHeat                    (XD3T)

P165E                    9-pin                    Green                    Top of Speedo

- 1- LH Turn
- 2- \_\_\_\_\_
- 3- Lights On
- 4- Low Beam
- 5- High Beam
- 6- RH Turn
- 7- Delay off
- 8- \_\_\_\_\_
- 9- \_\_\_\_\_

P165F                    10-pin                    White                    Right of Speedo

- 1- Oil Pressure
- 2- \_\_\_\_\_
- 3- Coolant
- 4- Trans. Temp                    (XD3T/N9TE)
- 5- Oil Temp Gauge                    (XD3T/N9TE/ZN3J)
- 6- Oil Temp Light                    (XD3T)
- 7- Water in Fuel                    (XD3T)
- 8- Coolant Gauge
- 9- \_\_\_\_\_
- 10- LOW Coolant Light

P165G                    6-pin                    Gray                    Right of Panel

- 1- Fuel Gauge
- 2- Low Fuel Light

P165H                    4-pin                    Blue                    Bottom of Tach PCB

- 1- Run +
- 2- ECU
- 3- Ground
- 4- \_\_\_\_\_

P165J                    2-pin                    "Dark"                    Loose

- 1- ABS light
- 2- ABS light

P165K                    3-pin                    White                    top of Tach PCB

- 1- Oil Level Light                    (XD3T/N9TE/ZN3J)
- 2- Oil Level Light                    "
- 3- Hot +

P165M                    2-pin                    White                    Loose

- 1- Seat Belt +
- 2- Seat Belt